

Tools required:

- Flashlight
- Ratchet with 10mm socket and 3" extension
- Torx T15 screwdriver
- needlenose pliers

Install Time:

- 10-15mins

Instructions:


- 1) Push driver seat back as far as possible to gain some extra room.
- 2) Using the ratchet, 10mm socket and a 3" extension remove the 3 nuts that hold the accel pedal assembly to the firewall. (see image below) 2 nuts on top, 1 nut on bottom left.
- 3) There is no need to disconnect the harness from the pedal assembly. All we want to do is to gain access to the back of the accel pedal.
- 4) Turn the assembly on it side and look behind the pedal. You should see a pair of nylon insert lock nuts
- 5) Use both the needle-nosed pliers and a T15 torx screwdriver to remove the mounting hardware and accel plate from the pedal assembly.
- 6) Place the new accel pedal plate on the assembly and feed the torx screws through the hole. Now comes the hard part, as it requires some dexterity. Using needle-nosed pliers slide on the pair of washers and then hold the nylon lock nut in place. To start threading the screw to the lock nut, grab your torx screwdriver and turn the screw. If you can thread it on the first try....you are awesome!
- 7) Bolt the accel pedal assembly back to the firewall.

ACCELERATOR PEDAL REMOVAL/INSTALLATION[LF, L3]

W0113a5801400

1. Remove in the order indicated in the table.
2. Install in the reverse order of removal.

1	Connector
2	Installation nut
3	Accelerator pedal



E3U113ZW6011